
## **Changing Fonix 8000 Battery**

Gently turn Fonix 8000 on its side and remove bottom panel to expose battery.



Replace battery with CR2032 3V Battery with + side up.

